

Onderdelen voor WH18DBSLW4Z

nÂ°	Artikel	Aantal gebruikt
1	330619 RETAINING RING	1
2	330856 WASHER (D)	1
3	331284 GUIDE SPRING (D)	1
4	339350 GUIDE SLEEVE NEW	1
5	372204 FRONT CAP	1
6	372205 HAMMER CASE	1
7	370579 WASHER (F) NEW	1
8	319535 STEEL BALL D3.5 (10 PCS)	2
9A	376498 ANVIL (L)	1
9A	376497 ANVIL (S)	1
10	335329 HAMMER NEW	1
11	959148 STEEL BALL D3.175 (10 PCS)	28
12	315978 WASHER (J)	1
13	336640 HAMMER SPRING (K)	1
14	316172 WASHER (S)	1
15	328647 STOPPER (C)	1
16	959154 STEEL BALL D5.556 (10 PCS) (OLD 939277Z)	2
17	326295 IDLE GEAR SET (2 PCS) (OLD 321667)	2
18	333747 RING GEAR (E)	1
19	983852 O-RING (S-42)	1
20	370583 WASHER (E) NEW	1
21	6901VV BALL BEARING 6901VVCMP2L	1
22	324230 DAMPER (A)	2
23	335317 INNER COVER (E) NEW	1
24	361046 ROTOR PINION ASS'Y NEW	1
25	335723 BALL BEARING 604DD NEW	1
26	372208 SPINDLE	1
27	319914 NEEDLE ROLLER	2
28	372202 HOUSING (A).(B) SET	1
29	BRAND LABEL	1
30	327001 TRUSS HD. SCREW M4 (BLACK)	1
31	336372 HOOK NEW	1
32	324225 PUSHING BUTTON (B)	1
33	339217 DC-SPEED CONTROL SWITCH NEW	1
34	372203 WIRING ASS'Y	1
35	313687 TAPPING SCREW (W/FLANGE) D3X16 (BLACK)	9
36	NAME PLATE	1
37	306952 STRAP (BLACK)	1

Onderdelen voor WH18DBSLW4Z

nÂ°	Artikel	Aantal gebruikt
38	370728 TERMINAL RUBBER (A) NEW	1
39	336265 BATTERY BSL 1850 (CHN)	2
39	336266 BATTERY BSL 1850 (TPE)	2
39	335790 BATTERY BSL 1850 (EUROPE,AUS,NZL)	2
501	329897 BATTERY COVER	1
502	CHARGER (MODEL UC 18YFSL)	1
503	336642 CASE	1
504	336471 CASE ASS'Y (STACKABLE)	1
505	336472 LATCH	4
506	336473 HANDLE	1
507	336474 HINGE	2
508	336475 INNER TRAY	1
601	983006 + DRIVER BIT NO.2 65L	1
602	983011 + DRIVER BIT NO.3 65L	1
603	992671 + DRIVER BIT (B) NO.2 50L	1
604	992672 + DRIVER BIT (B) NO.3 50L	1
605	955657 - DRIVER BIT (A) 3MMX70L	1
606	955659 - DRIVER BIT (A) 4MMX70L	1
607	955674 - DRIVER BIT (A) 6MMX70L	1
608	321823 DRILL CHUCK AND ADAPTER SET	1
609	307543 CHUCK ADAPTER	1
610	987575 CHUCK WRENCH FOR 10VLB-D,10VLR-D	1
611	309922 GREASE FOR IMPACT DRIVER (500G)	1
612	325149 GREASE (MOLUB-ALLOY NO.777-1) 75G	1
613	306927 SILICON RUBBER	1
614	996184 BIT PIECE	1
615	996177 NON-MAGNETIC HEX. SOCKET 8MM 65L	1
616	985329 NON-MAGNETIC HEX. SOCKET 10MM 65L	1
617	996178 NON-MAGNETIC HEX. SOCKET 12MM 65L	1
618	996179 NON-MAGNETIC HEX. SOCKET 13MM 65L	1
619	996180 NON-MAGNETIC HEX. SOCKET 14MM 65L	1
620	996181 NON-MAGNETIC HEX. SOCKET 16MM 65L	1
621	996182 NON-MAGNETIC HEX. SOCKET 17MM 65L	1
622	996197 HEX. SOCKET (LONG) 21MMX166L	1

Onderdelen voor WH18DBSLW4Z

